#### BEAUTY & PERSONAL CARE FORMULATION CARD | CANADA



# Rescue Remedy Pressed Serum

This K Beauty inspired formula provides a truly unique experience with its transforming texture; it is supercharged with a unique blend of 5 powerful peptides. Fortified by Portulaca extract, with proven anti-inflammatory, skin soothing and anti-oxidant activity. This hybrid pressed serum addresses the first visible signs of aging by recharging fatigued skin, visibly reducing fine lines and wrinkles, and refining dull, uneven texture. This unique formula breaks into a serum upon application and melts into the skin to provide a smooth, supple, and radiant complexion.



#### Aculyn<sup>™</sup> 28

A unique emulsifying polymer that provides a jelly- like texture, it has a sheer thinning effect upon application, enabling the transforming texture.

#### DOWSIL<sup>™</sup> EL-8048 ID Silicone Organic Blend

A versatile Silicone Elastomer, which enables time saving products. It has the ability to control the release of actives over several hours. It has a wide compatibility profile, with both organics and silicones, a low D4/D5 content and it is China approved.

#### **Portulaca Extract-TLS**

This is a natural choice for dry and sensitive skin. The source of this extract, P. oleracea, is well known in oriental herbal medicine and is one of the richest green plant sources of omega-3 fatty acids. Recent scientific research showed that P. oleracea exhibited a wide range of biological activity including antiinflammatory, anti-oxidant and wound healing activities.

### **Rescue Remedy Pressed Serum**

#	TRADE NAME		FUNCTION	WT%	SUPPLIER				
PH	PHASE 1								
1	Water	Aqua	Diluent	61.4	Univar Solutions				
2	Aculyn <sup>™</sup> 28	AcrylatesCopolymer	Emulsifier, - Jelly-like texture, transforming texture, independent of HLB	2.5	DOW®/ Univar Solutions				
3	AMP-ULTRA PC 2000 (5% water)	Aminomethyl Propanol	Globally approved for PC use, neutralizer	Q.S	Angus/ Univar Solutions				
4	MOON OU (natural, 99.7%)	Glycerin	Humectant	5.0	Procter & Gamble /Univar Solutions				
5	Sepigel 305	Polyacrylamide (and) C13-14 Isoparaffin (and) Laureth-7	Emulsifier	0.6	Seppic				



## **Rescue Remedy Pressed Serum**

#	TRADE NAME	INCI NAME	FUNCTION	WT%	SUPPLIER
6	Portulaca Extract-TLS	Portulaca Oleracea Extract	Anti-aging, anti-inflammatory	3.0	The Garden of Natural Solution
7	DermaPep <sup>™</sup> YouCel	Myristoyl TriPeptide-31, Myristoyl TetraPeptide-6, Myristoyl TetraPeptide-34, Palmitoyl PentaPeptide-4, Methyl Undecenoyl Leucinate	Anti-wrinkle, anti-aging, skin lifting, regeneration, brightening and lightening, sun protection	3.0	Bead tech/ Univar Solutions
PH.	ASE 2				
8	DOWSIL <sup>™</sup> EL-8048 ID Silicone Organic Blend	Isododecane(and) DimethiconeCrosspolymer	Provides dry smoothness and a light, silky, non-greasy skin feel, quick absorption, low transfer, low D4/D5, China approved.	20.0	DOW®/ Univar Solutions
9	DOWSIL <sup>™</sup> FZ-3196 Cosmetic Fluid	Caprylyl Methicone	Light, silky feel, excellent spread-ability, moderate volatility with excellent compatibility with a wide range of cosmetic ingredients (such as natural oils), reduces greasiness and tackiness	2.0	DOW®/ Univar Solutions
10	HydraSynol <sup>™</sup> IDL	Isosorbide Disunflowerseedate	Hydration, barrier builder, skin radiance, skin protection against oxidative stress and inflammation	2.0	Sytheon/ Univar Solutions
PH	ASE 3				
11	Neolone <sup>™</sup> PH 100	Phenoxyethanol	Preservative	0.5	DOW®/ Univar Solutions
		Total		100%	

1. Melt material 3 ( 40°C).

PROCEDURE

- 2. Mix ingredients of phase 1 together.
- 3. In a separate vessel, mix phase 2 until homogeneous.
- 4. Slowly add phase 2 to phase 1 (mix at 700 rpm and increase rpm during addition of phase 2).
- 5. Homogenize for 5 minutes (the viscosity will increase, as the particle size is being broken down during homogenization).
- 6. Add phase 3 to phase 1,2.

Univar Solutions Inc. and its affiliates ("Univar") offer this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation. BEFORE USE, YOU MUST TEST THE FORMULATION, OR ANYVARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. FURTHERMORE, IT IS YOUR RESPONSIBILITY TO OBTIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. BY TAKING THIS SUGGESTED FORMULATION, YOU HEREDY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. © 2020 Univar Solutions Inc. All rights reserved. Univar, the collaboration insignia, and other identified trademarks are the property of Univar Solutions Inc. or affiliated companies. All other trademarks not woned by Univar Solutions Inc. or affiliated companies that appear in this material are the property of their respective owners. PC-CAN-BPC-1035-0320

