

	Tra	ade name	INCI name	Supplier	%
Α	1	Water	Aqua	Univar*	Qs 100%
	2	Aculyn™ Excel	Acrylates Copolymer	Dow Personal Care/Univar*	6.5
	3	EMAL 270D	Sodium Laureth Sulfate	Kao Personal Care/Univar*	14.29
В	4	EcoSense 919 Surfactant	Coco-glucoside	Dow Personal Care/Univar*	3.92
	5	Empigen Total active TC/U	Cocamidopropyl betaine	Huntsman/Univar*	5.88
С	6	Sodium Hydroxide (30%) Qs to pH 8.0	Sodium Hydroxide	Univar*	Qs to pH8
D	7	Salicylic acid	Salicylic acid	Novacyl/Univar*	0.50
Е	8	Citric acid	Citric acid	Jungbunzlauer/Univar*	
F	9	Water	Aqua	Univar*	9.80
	10	SoftCAT SK-MH Conditioning Polymer	Polyquarternium-67	Dow Personal Care/Univar*	0.20
G	11	Fragrance – Fruity Candies SX137838	Parfum	Kao Chemicals Europe/ Univar*	0.08
Н	12	Unihearts R0-652C	Mannitol, Cellulose, Acrylates Copolymer, Hydroxypropylcellulose, Decyl Glucoside, Caprylic/Capric Triglyceride, Acrylates/ Ammonium Methacrylate Copolymer, Talc, Mica, Triethyl Citrate	Induchem	0.1
	13	Mix Vision beads with Vitamin E	Manitol, Cellulose, HPMC, Titanium Dioxide, Red Iron Oxide, Yellow Iron Oxide, Chromium Oxide Green, Vitamin E	IMPACT COLORS, INC./ Univar*	0.15
	14	Lavender extract LG	Lavandula angustifolia flower extract	Naturex/Univar*	0.5

^{*} Please contact your regional Univar Sales Representative to ensure that mentioned products are distributed in your country.

Reference: 171014.CC(U)

Issued by: Univar's European PC Laboratory in Brussels, Belgium

Contact: personalcareEMEA@univar.com

Procedure (Cold Process)

- Mix together the ingredients of phase A until uniform
- 2. Add ingredients of phase B under stirring
- 3. Increase the pH to pH 8.0 (not exceeding pH 10) by adding phase C $\,$
- 4. Add phase D
- 5. Add phase E decrease pH to 4.8
- In a separate mixing vessel mix ingredients of phase F and stir until complete dissolution. Hydration of SoftCat can be accelerated by heating the solution to 65°C or by increasing the alkalinity of the solution.
- 7. Add F to A-E
- 8. Add ingredient of phase G
- 9. Add ingredients of phase H

Stability

Stable at least 3 months at RT and 40°C

Comments

Viscosity (Brookfield RVDV-II+ Pro, spindle 5, 30 rpm, 1 min) = 8 040 cPs (60.3%) pH = 5.03

Product Appearance: A crystal clear transparent gel which suspends coloured beads and red heart films.

This formulation was inspired from "Love Me" Shower Gel for Teens developed by Dow Personal Care and showcased at SCS 2014



Disclaimer – Univar BV and its affiliates ("Univar") offers this suggested formulation on only, it is not a commercialized product. Univar nelies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety. Univar makes no warranties, express or implied, related to five done any patent search on the suggested formulation. BEFORE USE, YOU MUST TEST THE FORMULATION, OR ANY VARANCE THEREOF, TO DETERMINE THE PREFORMANCE, EFFICACY AND SAFETY, FURTHERMORE, IT IS YOUR RESPONSIBILITY TO ORSTAIN ANY NECESSARY OCYRENMENT CLEARANCE, LICENSE OR REGISTRATION. BY TAKING THIS SUGGESTED FORMULATION, YOU HERBY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. a 2015. Univar, inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00007598-2015