



Perfect Pout Lip Duo Mask

For a perfect pout we created a scrub & mask combo to whip even the most neglected lips into tip top condition.

Pucker up! A creamy emulsion thickened by **ACULYN™ 38 Polymer** and **Methocel™ 40-100 PCG** is the perfect treatment for dry lips. This mask is rich in emollients such as **Ercarel TCC V** and **Ercarel PGDD V** and natural **Virgin Chia Oil**. **Dow Corning® FA4003 DM Silicone Acrylate** forms a light film making for an easy application. Coupled with **UCON™ Fluid AP**, we achieve a non-stick, lubricious mask. We know wrinkle-free, smooth lips are lust worthy and we've got you covered. **Dow Corning® 9576 Smooth Away Elastomer** is specially dedicated to creating soft focus blur effects and contributes to the velvety feel. It smoothes lip lines and reduces wrinkles thus creating the perfect base before lipstick application. **Cherry Blossom Eutectys**, issued from a newly patented extraction process, firms and its regenerative and antioxidant properties help repair the skin barrier.

 **UNIVAR®**
PERSONAL CARE

	Trade name	INCI name	Supplier	%	
A	1	Water (aqua)	Univar*	Q.S	
	2	Glycerin	Univar*	5.0	
	3	ACULYN™ 38 Polymer	Acrylates/Vinyl Neodecanoate Crosspolymer	Dow Personal Care / Univar*	5.0
	4	METHOCEL™ 40-100 PCG	Hydroxypropyl Methylcellulose	Dow Personal Care / Univar*	1.0
B	5	NaOH (33% solution)	Sodium Hydroxide	Univar*	0.5
C	6	UCON™ Fluid AP	PPG-14 Butyl Ether	Dow Personal Care / Univar*	3.0
	7	Chia Oil Virgin Deodorized LA030045	Salvia hispanica Seed Oil	Naturex / Univar*	1.5
	8	Ercarel TCC V	Caprylic/Capric Triglyceride	Erca Wilmar / Univar*	5.0
	9	Ercarel PGDD V	Propylene Glycol Dicaprylate Dicaprate	Erca Wilmar / Univar*	2.0
	10	<i>Dow Corning®</i> 9576 Smooth Away Elastomer	Dimethicone (and) Dimethicone/Vinyl Dimethicone Crosspolymer (and) Dimethicone Crosspolymer (and) Beeswax (and) Silica (and) Silica Silylate	Dow Corning / Univar*	5.0
	11	<i>Dow Corning®</i> FA 4003 DM Silicone Acrylate	Dimethicone (and) Acrylates/Polytrimethylsiloxymethacrylate Copolymer	Dow Corning / Univar*	3.0
D	12	Stabil	Phenethyl Alcohol (and) Caprylyl Glycol	Akema / Univar*	1.0
	13	Cherry Blossom Eutectys	Glycerin, Betaine, Aqua, prunus cerasus Flower Extract	Naturex / Univar*	0.4
	14	36011 Edicol Cramoisine	CI 14720	Univar Color / Univar*	0.3
	15	Beauty Night SX152734	Fragrance	Kao Fragrances / Univar*	0.4

Procedure (Cold process)

1. Mix ingredients of phase A together.
2. Add phase B until neutralization of Aculyn™.
3. Mix phase C in a separate vessel and add it to phase AB.
4. Add ingredients of phase D one by one.

Stability

Stable at least 2 months at room temperature, 40°C (still ongoing).

Comments

- Aspect: light pink creamy emulsion
- Application on the lips: lay down 5-10 min and remove the exceeding.
- Viscosity (spindle 6 ; 1 min) = 56,500 cPs
- pH : 7.12

* Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Reference: FR2916

Issued by: Univar's EMEA PC Laboratory in Versailles, France

Contact: personalcareEMEA@univar.com | www.univar.com



Disclaimer – Univar BV and its affiliates (“Univar”) offers this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety. Univar makes no warranties, express or implied, related to this suggested formulation, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation. BEFORE USE, YOU MUST TEST THE FORMULATION, OR ANY VARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. FURTHERMORE, IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. BY TAKING THIS SUGGESTED FORMULATION, YOU HEREBY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. © 2016. Univar Inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar Inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00008847-2016