

	Trade name	INCI name	Supplier	%
Α	1	Water ( Aqua)	Univar*	Q.S
	2	Glycerin	Univar*	7.0
В	3 Ercarel AB-V	C12-15 Alkyl benzoate	Erca Wilmar/ Univar*	5.0
	4 Cellosize HEC PCG-10	Hydroxyethyl Cellulose	Dow Personal care / Univar*	1.2
	5 Methocel™40-0100	Hydroxypropyl Methylcellulose	Dow Personal care / Univar*	0.6
С	6 AMP-Ultra™ PC 2000	Aminomethyl Propanol	Angus / Univar*	0.04
D	7 Dow Corning® EL-7040	Caprylyl Methicone (and) PEG-12 Dimethicone/ PPG-20 Crosspolymer	Dow Corning / Univar*	5.0
	8 GOLD MEN SM152715	Fragrance	Kao Fragrances / Univar*	0.08
	9 Vyox-G®	Lecithin (and) Tocopherol (and) Ascorbyl palmitate	Vevy / Univar*	0.01
E	10 Stabil Zero	Pentylene glycol, Caprylyl glycol, Ethylhexylglycerin	Akema / Univar*	0.5
	11 Aurealis™ LG	Glycerin, Aqua, citrus aurantium amara flower extract	Naturex / Univar*	0.6
	12 NC27 Vita Gly-Ginger	Zingiber Officinale (Ginger) Root Extract, Octyldodecanol, Alcohol denat, Hydrogenated lecithin, Phytosphingosine, Disteareth-2 lauroyl glutamate, Phytosterols, Squalane, Agar, Canola sterols, Glycerin	Vitalab / Univar*	0.6
	13 14-SA-3255 Brown HT Replacement	CI 19140, CI 1598, CI 14720, CI 42090	Univar Color	0.16
	14 Eldorado Red Gold MGM-307	Mica (CI 77019), TiO2 (CI 77891), Iron Oxide Red (CI 77491)	Sandream Impact / Univar*	0.1
F	15 Ethanol 99.9% S	Alcohol	Ineos / Univar*	7.0
G	16 Citric Acid (30% solution)	Citric Acid	Jungbunzlauer / Univar*	0.17

<sup>\*</sup> Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Reference: FR3616

Issued by: Univar's EMEA PC Laboratory in Versailles, France
Contact: personalcareEMEA@univar.com | www.univar.com

## Procedure (Cold process)

- Weigh ingredients of phase A and combine them with gentle stirring until homogeneous.
- 2. Combine B and mix at RT until a homogenous blend is obtained.
- 3. Add pre-mixed B to phase A under strong stirring.
- 4. Add C to AB whilst stirring.
- Add D to ABC whilst stirring until uniform.
- Add E to ABCD and mix.
- Add F to ABCDE whilst stirring.
- 8. Adjust pH between 5.5-6 with phase G.

## Stability

Stable at least 2 months at room temperature and 40°C (still ongoing).

## Comments

- pH = 5.4
- Viscosity = 58700 cps M6
- Application: Pour the gel into the palm of your hand. Apply gently onto the face.
   Avoid the eye area.
- Goldish brown gel, smooth, supple and shiny



Disclaimer — Univar BV and its affiliates ("Univar") offers this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety, Univar makes no warranties, express or implied, related to this suggested formulation, INCLIDING WARRANTIES OF MERCHATABILITY OR RITHORDES FOR A PARTICULAR PURPOSE Additionally, Univar has not done any patents reach on the suggested formulation in BEPORE USE, YOU MUST TEST THE PROMULATION, OR ANY VARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY, FURTHERMORE, IT IS YOUR RESPORTSAIL NATY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION, BY TAKING THIS SUGGESTED FORMULATION, YOU HEREBY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. a 2016. Univar inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00008485-2016