3D Magnetized Granite Hand Scrub

This is not your average hand scrub. It's filled with the power of the earth....Try a new gesture, smooth on this 3D magnetized emulsion for ultra smooth skin and a playful approach. The sandy rocks exfoliate and remove all dead cells, while **Syntadex MOF FV**, a mineral-oil free vaseline, gives moisturization without tackiness, and **Inchol**[®] helps calm and restructure the skin. This emulsion is thickened by **ACULYN[™] 38 Polymer** that provides a nice creamy texture and neutralized by **AMP-ULTRA[®] PC 2000**, a specialty neutralizing agent that improves pH and color stability. The **EcoSmooth[™] Delight** creates a pleasant sensory perception and cushion feel.



	Trade name	INCI name	Supplier	%
A	1	Water (Aqua)	Univar*	Q.S
	2 ACULYN [™] 38 Polymer	Acrylates/Vinyl Neodecanoate Crosspolymer	Dow Personal Care / Univar*	6.0
	3 AMP-ULTRA® PC 2000	Aminomethyl Propanol	ANGUS® / Univar*	Q.S pH 6.5
В	4 Ercamuls Lux	Cetearyl Alcohol, Glyceryl Stearate, PEG-40 Stearate, Ceteareth-20	Erca Wilmar	2.2
	5 Ercarel SHO	PEG-7 Glyceryl Cocoate, PEG-200 Hydrogenated Glyceryl Palmate	Erca Wilmar	2.0
	6 EcoSmooth™ Delight	C14-22 Alkane, Ethylene/Octene Copolymer	Dow Personal Care / Univar*	2.0
	7 Syntadex MOF FV	<i>Cera microcristallina</i> (and) Isoparaffine C18 - C50 (and) Synthetic Wax	Aiglon Groupe / Univar*	2.0
	8 Inchol®	Plukenetia volubilis Seed Oil	Aiglon Groupe / Univar*	2.0
	9 Sensolene®	Ethylhexyl Olivate	Hallstar / Univar*	2.0
С	10 Stabil	Phenethyl Alcohol and Caprylyl Glycol	Akema / Univar*	1.2
D	11 Magnetite Exfoliator 500	Sand	Lessonia	3.25
	12 Fiesta Silver Sparkle FW-8600K	Synthetic Fluorphlogopite, Titanium Dioxide (CI 77891)	Sandream Impact / Univar Colour*	3.0
	13 Sterling Super Galaxy Silver S5256	Aluminum Calcium Sodium Silicate (and) Silver	Sandream Impact / Univar Colour*	0.5
	14 Sterling Shimmer Silver S022	Aluminum Calcium Sodium Silicate (and) Silver	Sandream Impact / Univar Colour*	0.5
	15 Rose Gold SY153974	Fragrance	Kao Fragrances / Univar*	0.3

Procedure (Hot process)

- Mix phase A and neutralize ACULYN[™] 38 Polymer, heat to 65°C
- 2. In a separate vessel, heat and mix phase B
- 3. Add phase B to phase A with vigorous mixing and continue heating
- 4. Cool down to RT and add phase C and D

Stability

Stable 2 months at 4°C, room temperature and 40°C.

Comments

• pH:6.5

- Viscosity (spindle 7 ; 10 rpm ; 1 min) = 107 630 cPs
- Silver creamy emulsion with black magnetite exfoliators
- Application : massage on your hand and rinse after exfoliation

* Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

 Reference:
 FR2117 4

 Issued by:
 Univar's EMEA PC Laboratory in Versailles, France

 Contact:
 personalcareEMEA@univar.com | www.univar.com



Disclaimer – Univar BV and its affiliates ("Univar") offers this suggested formulation as a representative formulation on the suggested formulation as a representative formulation to this aggested formulation in formation and data from its suppliers on which to base this suggested formulation to this suggested formulation to any testing for performance, efficacy or safety. Univar makes no warranties, express or implied, related to this suggested formulation. INCLUDING WARRANTES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not subjected the suggested formulation to the suggested formulation between the suggested formulation to the suggested formulation. INCLUDING WARRANTES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation between the STORE USE, YOU MUST TEST THE FORMULATION, OR ANY VARIANCE THERCE, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY, FURTHERMORE, ITS VOUR RESPONSIBILITY TO OBTAIN ANY INCESSARY COVERNMENT CLEARANCE, LICENSE OR REGISTRATION BY TAKING THIS SUGGESTED FORMULATION, YOU HEREBY AGREE TO DEFEND AND HOLD UNIVAR HARNLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINCEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. © 2017. Univar Inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar Inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00007932-2017