



Blue Steel Sebum Control Essence

Shiny instead of glowing? This product is for you. It is especially dedicated to control the sebum on your face. Bring back confidence and stop that mid-day blotting session. This essence is incredibly comfortable to wear and has a super silky touch thanks to **Dow Corning® 3901 Liquid Satin Blend**, that also optimizes efficacy. **Dow Corning® EP-9801 Hydro Cosmetic Powder**, an innovative hydrophilic silicone, provides a smooth and powdery feel, soft focus effect, as well as sebum and oil absorption. That amazing blue steel color is created by mixing two glitters: **Chromatique Silver Gray** and **Glamour Glowing Blue G8252**. Be the envy of all your friends.



	Trade name	INCI name	Supplier	%
A	1 ISOSTEARENE	Isodecyl Laurate	Vevy Europe / Univar*	2.0
	2 Sensolene®	Ethylhexyl Olivat	Hallstar / Univar*	5.0
B	3 Dow Corning® 3901 Liquid Satin Blend	Dimethicone/Vinyl Dimethicone Crosspolymer (and) Dimethicone	Dow Corning / Univar*	2.0
	4 XIAMETER® PMX 200 Silicone Fluid 1.5 cs	Dimethicone	Dow Corning / Univar*	3.0
C	5 Dow Corning® VM-2270 Aerogel Fine Particles	Silica Silylate	Dow Corning / Univar*	0.5
D	6 Dow Corning® RM 2051 Thickening Agent	Sodium Polyacrylate (and) Dimethicone (and) Cyclopentasiloxane (and) Trideceth-6 (and) PEG/PPG-18/18 Dimethicone	Dow Corning / Univar*	3.2
E	7	Water (Aqua)	Univar*	Q.5
	8 Dow Corning® EP-9801 Hydro Cosmetic Powder	Dimethicone/Vinyl Dimethicone Crosspolymer (and) Silica (and) Butylene Glycol	Dow Corning / Univar*	5.0
	9 37005 FD&C Blue n ¹ (1% in water)	CI 42090	Univar Colour*	0.32
	10 36004 Edicol Black PN (1% in water)	CI 28440	Univar Colour*	0.37
	11 Stabil	Phenethyl Alcohol and Caprylyl Glycol	Akema / Univar*	1.0
F	12 Iron SY153978	Fragrance	Kao Fragrances / Univar*	0.2
	13 Chromatique Silver Gray MCM-4407	Mica [CI 77019] (and) Titanium Dioxide [CI:7789] (and) Iron Oxide Black [CI 77499]	Sandream Impact / Univar Colour*	0.2
	14 Glamour Glowing Blue G8252	Aluminum Calcium Sodium Silicate (and) Titanium Dioxide [CI 7789] (and) Tin Dioxide [CI 7786] (and) FD&C Blue 1 [CI:42090]	Sandream Impact / Univar Colour*	0.21

* Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Reference: FRI017 2

Issued by: Univar's EMEA PC Laboratory in Versailles, France

Contact: personalcareEMEA@univar.com | www.univar.com

Disclaimer – Univar BV and its affiliates ("Univar") offers this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety. Univar makes no warranties, express or implied, related to this suggested formulation, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation. BEFORE USE, YOU MUST TEST THE FORMULATION, OR ANY VARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. FURTHERMORE, IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION, BY TAKING THIS SUGGESTED FORMULATION, YOU HEREBY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. © 2017, Univar Inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar Inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00009327-2017



Procedure (Cold process)

1. Weigh ingredients of phase A and combine them with gentle stirring until homogeneous
2. In a separate vessel, blend B until uniform
3. When completely clear, add slowly pre-mixed B to A and mix until uniform
4. Add C to AB and stir until powder is homogeneously dispersed
5. Add D to ABC slowly
6. In a separate vessel, weigh ingredients of phase E and combine them with gentle stirring until homogeneous
7. Slowly add E to ABCD with good mixing until uniform
8. As the formulation thickens, increase the mixing rate of ABCDE until a homogenous cream is obtained
9. Add F in order to the batch, mixing to ensure uniformity between additions

Stability

Stable 2 months at 4°C, room temperature and 40°C.

Comments

- pH = 5.80
- Viscosity (spindle 5; 10 rpm; 1 min) = 38 640 cPs
- Formula inspired from "Facial Cream: Sebum absorption, Snow white, Sun care lotion" (formulation CPF 00972) developed by our partner, Dow Corning.
- Smooth and soft blue cream, non greasy, sebum absorber.
- Application: Take a dollop of cream and massage onto your face.