

	Trade name	INCI name	Supplier	%
	1	Water (Aqua)	Univar*	Q.S
Α	2 ACULYN™ Excel	Acrylates Copolymer	Dow Personal Care / Univar*	5.0
	3 AKYPO® Soft 100 BVC	Sodium Laureth-11 Carboxylate	Kao Chemicals Europe / Univar*	3.0
В	4 NaOH (33% solution)	Sodium Hydroxide, Water	Univar*	0.84
С	5 Citric Acid Monohydrate CAM NI560 (30% solution)	Citric Acid, Water	Univar*	0.18
D	6 UCARE™ Polymer JR 30M	Polyquaternium-10	Dow Personal Care / Univar*	0.5
	7	Water (Aqua)	Univar*	10.0
Е	8 ACULYN™ 22 Polymer	Acrylates/Steareth-20 Methacrylate Copolymer	Dow Personal Care / Univar*	1.0
F	9 Stabil	Phenethyl Alcohol and Caprylyl Glycol	Akema / Univar*	2.0
	10 White Dream SY153248	Fragrance	Kao Fragrances / Univar*	0.2
	11 FINDET® ARH/52	PEG-40 Hydrogenated Castor Oil	Kao Chemicals Europe / Univar*	0.2
	12 Garnet Exfoliator 300	Aluminum Silicate	Lessonia	3.0
G	13 Vida-Caps 1114	Shea butter (and) Mica (and) Xanthan gum (and) Chitosan* (and) Acacia senegal (and) Phenoxyethanol (and) Sodium Benzoate (and) Dehydro-Acetic acid *non-animal-derived	Lambson / Univar*	4.0

^{*} Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Procedure (Warm process)

- Combine and mix ingredients of phase
 A
- 2. Increase the pH above 8 with phase B
- 3. Adjust the pH to 6,5-7 with phase C
- 4. Combine and heat phase D to 40°C and add it into phase ABC
- 5. Add phase E
- Combine and heat phase F to 40°C and add it into phase ABCDE, adjust pH to 6-6,5 if necessary
- 7. Add phase G with very gentle stirring

Stability

Stable 2 months at 4°C, room temperature and 40°C.

Comments

- pH = 6.44
- Viscosity (spindle 4; 20 rpm; 1 min) = 7 000
- Gel with copper and black particles suspended
- Application: Rinse-off product

Reference: BE5116 7

Issued by: Univar's EMEA PC Laboratory in Brussels, Belgium
Contact: personalcareEMEA@univar.com | www.univar.com



Disclaimer — Univar BV and its affiliates ("Univar") offers this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety, Univar makes no warranties, express or implied, related to this suggested formulation. INCLUDING WARRANTIES OF MERCHAINTIES OF MERCHAINTIES