



## White Marble Hydrate & Prime Perfecting Base

This pearly white daily cream will hydrate and perfect your skin for a photo ready look in just one gesture! Thanks to **Dow Corning® 9576 Smooth Away Elastomer**, all your little imperfections will be completely forgotten. This special silicone elastomer gives a powerful soft-focus effect to this cream, masking all pores and wrinkles. It is the perfect base for your makeup routine or can be used alone for a very natural look. Time for a selfie... Its broad compatibility enables its use with natural butters and fatty alcohols, to bring additional moisturizing properties. The **Dow Corning® 3901 Liquid Satin Blend** provides a unique luxurious texture for a great sensorial experience. The system is thickened by **ACULYN™ 38 Polymer**, neutralized by **TRIS AMINO® ULTRA PC**, a high specialty neutralizing agent with excellent safety profile. No filter necessary, this formula is tried and tested. Are you ready for a close-up? #nofilterneeded

 **UNIVAR®**  
PERSONAL CARE

	Trade name	INCI name	Supplier	%	
A	1	Water (Aqua)	Univar*	Q.S	
	2	ACULYN™ 38 Polymer	Dow Personal Care / Univar*	4.0	
	3	TRIS AMINO® ULTRA PC	ANGUS® / Univar*	0.3	
B	4	Glycerin	Univar*	2.5	
	5	Glyceryl Stearate (and) PEG-100 Stearate		2.5	
	6	Cetearyl Alcohol		2.2	
	7	Cupuacu Butter	<i>Theobroma grandiflorum</i> Seed Butter	Univar*	3.0
C	8	XIAMETER® PMX 200 Silicone Fluid 2 cs	Dow Corning / Univar*	2.0	
	9	Dow Corning® 3901 Liquid Satin Blend	Dimethicone/Vinyl Dimethicone Crosspolymer (and) Dimethicone	Dow Corning / Univar*	2.0
D	10	Dow Corning® 9576 Smooth Away Elastomer	Dimethicone (and) Dimethicone/Vinyl Dimethicone Crosspolymer (and) Dimethicone Crosspolymer (and) Beeswax (and) Silica (and) Silica Silylate	Dow Corning / Univar*	5.0
E	11	Stabil Zero	Pentylene glycol, Caprylyl glycol, Ethylhexylglycerin	Akema / Univar*	1.2
	12	Beauty Coco SRI49550	Fragrance	Kao Fragrances / Univar*	0.09
	13	Optique Pearl Copper	Mica [CI:77019] (and) Titanium Dioxide [CI 77891] Tin Dioxide [CI 77861]	Sandream Impact / Univar Colour*	0.05

\* Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Reference: FR2417 4

Issued by: Univar's EMEA PC Laboratory in Versailles, France

Contact: [personalcareEMEA@univar.com](mailto:personalcareEMEA@univar.com) | [www.univar.com](http://www.univar.com)

Disclaimer – Univar BV and its affiliates (“Univar”) offers this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety. Univar makes no warranties, express or implied, related to this suggested formulation, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation. BEFORE USE, YOU MUST TEST THE FORMULATION, OR ANY VARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. FURTHERMORE, IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. BY TAKING THIS SUGGESTED FORMULATION, YOU HEREBY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. © 2017, Univar Inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar Inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00009337-2017

Procedure (Hot process)
1. Add the ACULYN™ 38 Polymer to water and neutralize with TRIS AMINO® ULTRA PC
2. Heat to 65°C
3. Mix constituents of phase B and heat to 65°C
4. Add phase B to phase A while stirring
5. Cool down to RT and mix constituents of phase C
6. Add it to phase AB and add phase D
7. Add constituents of phase E in order

Stability
Stable 2 months at 4°C, room temperature and 40°C.

Comments
• pH : 6.8
• Viscosity (spindle 5 ; 10 rpm ; 1 min) = 26 120 cPs
• Pearlescent white emulsion with soft-focus effects
• Application: use it as hydrating daily cream, it will mask all skin imperfections and makes it ready for make-up

