

	Trade name		INCI name	Supplier	%
Α	1		Water (Aqua)	Univar*	Q.S
	2	ACULYN™ 28 Polymer	Acrylates/Beheneth-25 Methacrylate Copolymer	Dow Personal Care / Univar*	3.8
	3		Glycerin	Univar*	3.0
	4	Propylene Glycol	Propylene Glycol	Univar*	5.0
В	5	AMP-ULTRA PC 2000	Aminomethyl Propanol	Angus / Univar*	Q.S 6 < pH < 7
С	6		Water (Aqua)	Univar*	14.0
	7	SoftCAT™ SX-1300H	Polyquaterium-67	Dow Personal Care / Univar*	0.4
	8	UCON™ 75-H-450	PEG/PPG-17/6 Copolymer	Dow Personal Care / Univar*	8.0
D	9	Avocado Oil Refined	Persea gratissima (Avocado) Oil	Hughes & Co / Univar*	1.0
	10	Moringa Oil Refined	Moringa oleifera Seed Oil	Hughes & Co /Univar*	1.0
	11	Vitamin E Acetate	Tocopheryl Acetate	Rita / Univar*	0.2
	12	Vida-Care USB-25	Octocrylene, Butyl Methoxydibenzoylmethane, Benzophenone-3, Ethylhexyl Methoxycinnamate, Ethylhexyl Salicylate, C12-13 Alkyl Lactate	Lambson / Univar*	6.0
Е	13	Coton Blanc SY153247	Fragrance	Kao Fragrances / Univar*	1.0
	14	Stabil ZERO	Pentylene glycol, Caprylyl glycol, Ethylhexylglycerin	Akema / Univar*	1.5

^{*} Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Procedure (Cold process)

- Prepare phase A under gentle stirring until homogeneous.
- Adjust pH by adding phase B under gentle stirring until homogeneous.
- Prepare phase C under gentle stirring until homogeneous (hydration of SoftCAT™ can be accelerated by heating the solution to 65°C or by increasing the alkalinity of the solution).
- 4. Add phase C into blend with stirring until homogeneous.
- Add phase D under stirring until homogeneous (homogenize 1min/100g with Ultra Turrax).
- 6. Add phase E one by one under gentle stirring until homogeneous.

Stability

Stable at least 1 month at room temperature, 40°C and 50°C (still ongoing)

Comments

- Viscosity (spindle 3; 6 rpm; 1 min) = 13,150 cPs (78.9%)
- pH = 6.11
- Leave-on hair care white fluid: odor refresher, anti-pollution, and manages hair
- Application: finger-comb, wet-comb or dry-comb, this leave-in conditioning serum can be applied at any time

Reference: BE4516

Issued by: Univar's EMEA PC Laboratory in Brussels, Belgium
Contact: personalcareEMEA@univar.com | www.univar.com



Disclaimer — Univar BV and its affiliates ("Univar") offers this suggested formulation as a representative formulation only, It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety. Univar makes no warranties, express or implied, related to this suggested formulation, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNSE OF A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation. BEFORE USE, "YOU MUST TEST THE FORMULATION, OR ANY VARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY, PURTHERMORE, IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. BY TAKING THIS SUGGESTED FORMULATION, YOU HERBY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. a 2016, Univar Inc. All rights reserved. Univar, the hexagon and the Univar logs are registered trademarks of Univar Inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00009911-2016