

	Tra	ade name	INCI name	Supplier	%
Α	1		Water (Aqua)	Univar*	Q.S
	2	Danox® HC-30	Behenamidopropyl Dimethylamine (and) Dipalmitoylethyl Hydroxyethylmonium Methosulfate (and) Cetyl Alcohol (and) Stearyl Alcohol (and) Lactic Acid	Kao Chemicals Europe / Univar*	3.0
	3	Propylene Glycol	Propylene Glycol	Univar*	0.5
В	4		Water (Aqua)	Univar*	31.6
	5	Emanon® EV-E	Glycereth-7 Caprylate/Caprate	Kao Chemicals Europe / Univar*	2.0
С	6		Water (Aqua)	Univar*	3.89
	7	Amidet® N	PEG-4 Rapeseedamide	Kao Chemicals Europe / Univar*	3.89
	8	Dow Corning® CE-1874 Microemulsion	PEG-7 Dimethicone (and) Laureth-7 (and) Polysorbate 20	Dow Corning / Univar*	6.67
	9	Dow Corning® CB-3046 Fluid	Dimethicone (and) Phenyl Trimethicone (and) Trimethylsiloxysilicate (and) Dimethiconol	Dow Corning / Univar*	5.0
D	10	Biochemica® Moringa Oil NAT	Moringa oleifera Seed Oil	Hallstar	1.0
	11	Vitamin E Acetate	Tocopheryl Acetate	Rita / Univar*	0.2
	12	Vida-Care USB-25	Octocrylene, Butyl Methoxydibenzoylmethane, Benzophenone-3, Ethylhexyl Methoxycinnamate, Ethylhexyl Salicylate, C12-13 Alkyl Lactate	Lambson / Univar*	6.0
Ε	13	Coton Blanc SY153247	Fragrance	Kao Fragrances / Univar*	1.0
	14	Stabil ZERO	Pentylene glycol, Caprylyl glycol, Ethylhexylglycerin	Akema / Univar*	1.5
	15	Exceparl® LM-LC	Lauryl Lactate	Kao Chemicals Europe / Univar*	2.0

^{*} Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Reference: BE4516

Issued by: Univar's EMEA PC Laboratory in Brussels, Belgium
Contact: personalcareEMEA@univar.com | www.univar.com



Disclaimer — Univar BV and its affiliates ("Univar") offers this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation. Univar has not subjected the suggested formulation to any testing for promance, efficacy or safety. Univar makes no warrantice, express or implicit, eitabed to this suggested formulation, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation. BEFORE USE, YOU MUST TEST THIF FORMULATION, OR ANY VARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. FURTHERMORE, IT IS YOUR RESONBILITY TO DESTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION, BY TAKING THIS SUGGESTED FORMULATION, YOU HERBEY A GREET TO DEFEND AND HOLD UNIVAR HABMLESS ROW ANY CLAIM OF INTELLECTULA. PROPERTY INFRINCEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. e. 2016. Univar Inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar inc. Certain trademarks are owned by third parties, are used to identify the goods and service identified by those marks, and are the property of their rightful owners. 00009101-2016

Procedure (Hot process)

- Heat phase A up to 75°C and then stir until homogeneous at high speed (around 1000rpm during 3min).
- 2. Start cooling down phase A with gentle stirring.
- Pre-mix phase B and add it slowly into phase A under stirring. Temperature will decrease until room temperature.
- 4. Pre-mix phase C and add it under stirring until homogeneous.
- Add phase D under stirring until homogeneous (homogenize lmin/100g with Ultra Turrax).
- 6. Add phase E one by one under gentle stirring until homogeneous.
- Adjust pH if necessary with Lactic acid 88% (pH recommended between 3 and 4 to improve performance of Danox® HC-30 and formulation stability).

Stability

Stable at least 1 month at room temperature and 40°C (still ongoing).

Comments

- Viscosity (spindle 3; 30 rpm; 1 min) = 2,370 cPs (71.2%)
- pH = 4.06
- Leave-on hair care white fluid: odor refresher, anti-pollution, and manages hair
- Application: finger-comb, wet-comb or dry-comb, this leave-in conditioning serum can be applied at any time