

Clean Slate Make-up Remover



Leave nothing behind but the halo of your fresh, bare skin.

This two-part formula contains a separate water and oil phase which when shaken, work together to instantly hydrate skin and gently remove make-up.



XIAMETER® PMX-200, 50 CST Fluid: Skin protection. Imparts a soft, velvety skin feel. Spreads easily on both skin and hair. De-soaping (prevents foaming during rubout).



Glycerin, USP: An emollient that helps moisturize, soften and soothe skin and is a common ingredient in lotions, moisturizers and soap.



Mackstat® DM: Efficacious, broad spectrum, and cost effective antimicrobial. It is often sufficient by itself and can also be combined with other preservatives to provide enhanced antifungal activity.



New Elements, New You



Clean Slate Make-up Remover

COMPOSITION

Phase	Ingredients	% by Wt	Trade Name	Supplier
A	Water, Deionized	49.500		
	Glycerin	10.000	Glycerin, USP	Nexeo
	DMDM Hydantoin	0.500	Mackstat® DM	Nexeo / Solvay
B	Dimethicone	20.000	Xiameter® PMX-200, 50cs	Nexeo/ Dow
	Isohexadecane	20.000		

PROCEDURE

1. Combine phase A ingredients with mixing and pour into bottom of bottle.
2. Combine phase B ingredients with mixing and pour on top of phase A in the bottle.

PROPERTIES

Appearance: A clear top and bottom layer with distinct edge separation between the two layers.

FORMULATION NO.

NL-0027-107-2

TECHNICAL ASSISTANCE

For more information, to place an order, or request samples, contact Nexeo Solutions at **281.982.9447** or visit www.nexeosolutions.com.

The information in this document has been gratuitously provided by Nexeo Solutions. Although the statements, technical information and recommendations are believed to be accurate, NEXEO SOLUTIONS EXPRESSLY DISCLAIMS ANY AND ALL LIABILITY, EITHER EXPRESS OR IMPLIED arising from any use of the products or reliance on any information provided herein. This information is based on many factors beyond Nexeo Solutions' control, including but not limited to the completeness and accuracy of information received, or the conditions prevailing when operations were observed and/or sampled. In choosing to rely on or suggestions must be evaluated by you to determine their applicability or suitability for your particular uses. Nexeo Solutions is not engaged in rendering legal or other professional services and if such services are required, you should retain a competent professional to provide them. Any information claimed by Nexeo Solutions to be confidential or proprietary is not to be disclosed to any third party. Nothing contained herein constitutes a license to practice under any patent and should not be construed as an inducement to infringe on any patent.